




# Standard and Modular Electric Heater and Inserts Installation, Operation, and Maintenance Manual



**Modular Electric Heater**



**Electric Heat Module**



**Electric Insert**



## **RECEIVING AND INSPECTION**

Upon receiving unit, check for any interior and exterior damage, and if found, report it immediately to the carrier. Also check that all accessory items are accounted for and are damage free.

## **WARNING!!**

Installation of this equipment should only be performed by a qualified professional who has read and understands these instructions and is familiar with proper safety precautions. Improper installation poses serious risk of injury due to electric shock and other potential hazards. Read this manual thoroughly before installing or servicing this equipment. **ALWAYS** disconnect power prior to working on equipment.

**Save these instructions.** This document is the property of the owner of this equipment and is required for future maintenance. Leave this document with the owner when installation or service is complete.

## Table of Contents

WARRANTY .....	3
INSTALLATION .....	4
Mechanical .....	4
Service Clearance .....	4
Common Electric Heater Calculations .....	4
Applied vs Rated KW Factors .....	4
Curb and Ductwork .....	6
Roof Mount Installation .....	7
Installation with Exhaust Fan .....	7
Duct Mount Installation .....	8
Indoor (Inline) Installation .....	8
Heat Module Add-On Installation .....	9
ELECTRICAL .....	10
Fan to Building Wiring Connection .....	12
Remote Control Panel .....	12
Electric Cabinet Heater .....	13
AC Interlock .....	13
Motorized Intake Damper .....	13
Permanent Split Capacitor (PSC) Motor Speed Control .....	13
Electronically Commutated Motor (ECM) Speed Control .....	14
External PWM Signal .....	14
Unit Mount Controller .....	14
Motor Speed Controller (MSC) Installation .....	15
MSC Controls Overview .....	16
MSC Menu .....	16
Input Threshold .....	18
MSC Menu Tree .....	19
Heater Controller .....	20
Variable Frequency Drive (VFD) .....	21
Variable Frequency Drive (VFD) Installation .....	22
Input AC Power .....	22
VFD Output Power .....	22
VFD Programming .....	23
ACTECH SMV VFD .....	24
START-UP OPERATION .....	25
Start-up Procedure .....	25
Pulley Adjustment .....	26
Pulley Alignment/Proper Belt Tension .....	27
Pulley Combination Chart .....	28
Sequence of Operation .....	29
Main Circuit .....	29
Optional Remote Panel Circuit .....	30
Silicon Controlled Rectifier (SCR) Electrical Control .....	31
Modulating Coil Thermostat Settings .....	31
Thermostat with Dip Switch Settings .....	31
Thermostat without Dip Switch Settings .....	31
SCR Electrical Circuit Check .....	32
Components .....	33
Remote Panel Option .....	34
Troubleshooting .....	35
MSC Troubleshooting .....	37
MAINTENANCE .....	38
General Maintenance .....	38
2 Weeks After Start-up .....	38
Every 3 Months .....	38
Yearly .....	38
Unit Filters .....	39
Start-Up and Maintenance Documentation .....	40

## WARRANTY

This equipment is warranted to be free from defects in materials and workmanship, under normal use and service, for a period of 2-years from date of shipment. This warranty shall not apply if:

1. The equipment is not installed by a qualified installer per the MANUFACTURER'S installation instructions shipped with the product.
2. The equipment is not installed in accordance with Federal, State, or Local codes and regulations.
3. The equipment is misused or neglected, or not maintained per the MANUFACTURER'S maintenance instructions.
4. The equipment is not installed and operated within the limitations set forth in this manual.
5. The invoice is not paid within the terms of the sales agreement.

The MANUFACTURER shall not be liable for incidental and consequential losses and damages potentially attributable to malfunctioning equipment. Should any part of the equipment prove to be defective in material or workmanship within the 2-year warranty period, upon examination by the MANUFACTURER, such part will be repaired or replaced by MANUFACTURER at no charge. The BUYER shall pay all labor costs incurred in connection with such repair or replacement. Equipment shall not be returned without MANUFACTURER'S prior authorization, and all returned equipment shall be shipped by the BUYER, freight prepaid to a destination determined by the MANUFACTURER.

**NOTE: To receive warranty coverage for this product, copy and print out the "Start-Up and Maintenance Documentation" on page 40. Fill in all details required. Fax the page to 1-919-516-8710 or call 1-866-784-6900 for email information within thirty (30) days of purchase.**

## INSTALLATION

It is imperative that this unit is installed and operated with the designed airflow and electrical supply in accordance with this manual. If there are any questions about any items, please call the service department at **1-866-784-6900** for warranty and technical support issues.


### Mechanical

**WARNING: DO NOT RAISE UNIT BY THE INTAKE HOOD, BLOWER, MOTOR SHAFT, OR BEARINGS. USE ALL LIFTING LUGS PROVIDED WITH A SPREADER BAR OR SLING UNDER THE UNIT.**

### Site Preparation

1. Provide clearance around installation site to safely rig and lift equipment into its final position (**Figure 1**). Supports must adequately support equipment. Refer to manufacturer's estimated weights.
2. Locate unit close to the space it will serve to reduce long, twisted duct runs.
3. Consider general service and installation space when locating unit.
4. Do not allow air intake to face prevailing winds. Support unit above ground or at roof level high enough to prevent precipitation from being drawn into its inlet. The inlet must also be located at least 10 feet away from any exhaust vents. The fan inlet shall be located in accordance with the applicable building code provisions for ventilation air.

**Figure 1 - Spreader Bar**



### Service Clearance

Refer to **Table 1** for unit size clearance specifications. This will allow for enough clearance in the front, back and sides of the unit for servicing and maintenance of the unit.

**Table 1 - Clearance Chart**

Unit Size	Clearance
1	24"
2	36"
3	42"
4	48"
5	54"

### Common Electric Heater Calculations

Conversion:  
1 KW = 3413

Load Requirement:  
 $KW = (CFM \times \text{Temperature Rise}) / 3160$

Line Current (1 Phase):  
 $\text{Amperage} = (KW \times 1000) / \text{Volts}$

### Applied vs Rated KW Factors


Rated Voltage	Applied Voltage							
	200	208	220	230	240	440	460	480
208	.92	1.00	1.12	1.22	1.33	-	-	-
460	-	-	-	-	-	.91	1.00	1.09
480	-	-	-	-	-	.84	.92	1.00

## Intake Assembly

Intakes and curbs (Figure 2) are shipped on a separate skid. Upon unit arrival, perform the following steps to assemble the intake to the unit.

1. Apply silicone or weather-proof gasket on the backside of the flanges of the intake hood or V-bank intake.
2. Secure the flanges of the intake hood to the unit with the supplied sheet metal screws.
3. Use caulk on the outside of the screws to prevent water leaks.
4. If the unit is a modular unit with a V-bank or evaporative cooler section, the V-bank or evaporative cooler will bolt to the heater with the bolts provided.
5. Slide the filters down the filter track.

**Figure 2 - Intake and Curb Assembly**



## Curb and Ductwork

This fan was specified for a specific CFM and static pressure. The ductwork attached to this unit will significantly affect airflow performance. When using rectangular ductwork, elbows must be radius throat, radius back with turning vanes. Flexible ductwork and square elbows should not be used. Any transitions and/or turns in the ductwork near the fan outlet will cause system effect. System effect will drastically increase the static pressure and reduce airflow.

- **Table 2** shows the minimum fan outlet duct sizes and straight lengths required for optimal fan performance.
- Do not use the unit to support ductwork in any way. This may cause damage to the unit.
- **Follow SMACNA guides and manufacturer's requirements for the remaining duct run.** Fans designed for rooftop installation should be installed on a prefabricated or factory-built roof curb.
- Follow curb manufacturer's instructions for proper curb installation.
- The unit should be installed on a curb and/or rail that meets local code height requirements.
- Make sure the duct connection and fan outlet are properly aligned and sealed.
- Secure fan to curb through vertical portion of the ventilator base assembly flange. Use a minimum of eight (8) lug screws, anchor bolts, or other suitable fasteners (not furnished). Shims may be required depending upon curb installation and roofing material.
- Verify all fasteners are secure. **Figure 3** through **Figure 6** show different mechanical installations.

**Table 2 - Required Supply Ductwork**

Blower Size (Inches)	Discharge	Duct Size	Straight Duct Length*
10	Side	14" x 14"	48"
	Down		
15D, 16Z, 18Z	Side	20" x 20"	72"
	Down	14" x 14"	48"
12	Side	16" x 16"	54"
	Down		
15	Side	20" x 20"	72"
	Down		
20D, 20Z, 22Z	Side	26" x 26"	108"
	Down	20" x 20"	72"
18	Side	24" x 24"	86"
	Down		
24D, 25Z	Side	30" x 30"	108"
	Down	24" x 24"	86"
20	Side	26" x 26"	108"
	Down		
30D, 28Z	Side	32" x 32"	168"
	Down	26" x 26"	108"
25	Side	32" x 32"	168"
	Down		
36D	Side	36" x 36"	189"
	Down	32" x 32"	168"


**WARNING: ELECTRIC HEATERS HAVE TWO POWER INPUTS. THE EXTERNAL DISCONNECT INTERRUPTS POWER TO THE MOTOR AND CONTROLS ONLY. THE ELECTRIC COIL POWER IS INTERRUPTED BY THE DISCONNECT SWITCH ON THE ELECTRIC COIL DOOR.**

**Roof Mount Installation**

**Note: Refer to submittal drawings for specific unit dimensions.**

**Figure 3 - Roof Mount Details**

- 1. Discharge Opening
- 2. Curb Outer Wall
- 3. Flex Conduit for Field Wiring
- 4. Intake Housing
- 5. Lifting Lugs
- 6. Electric Heat Module
- 7. Service Disconnect Switch
- 8. Blower/Motor Access Door
- 9. Curb with Support Legs or Rail (20" High)
- 10. Control Drop
- 11. Motor Drop




**Max. Roof Opening 2" Smaller than Curb Outside Dimension.**

**Installation with Exhaust Fan**

**Note: Refer to submittal drawings for specific unit dimensions.**

**Figure 4 - Exhaust Fan Details**



- |                                  |                              |  |
|----------------------------------|------------------------------|--|
| 1. Discharge Opening             | 4. Intake Housing            | 8. Blower/Motor Access Door                  |
| 2. Curb Outer Wall               | 5. Lifting Lugs              | 9. Curb with Support Legs or Rail (20" High) |
| 3. Flex Conduit for Field Wiring | 6. Electric Heat Module      |  |
|                                  | 7. Service Disconnect Switch |  |


**WARNING: ELECTRIC HEATERS HAVE TWO POWER INPUTS. THE EXTERNAL DISCONNECT INTERRUPTS POWER TO THE MOTOR AND CONTROLS ONLY. THE ELECTRIC COIL POWER IS INTERRUPTED BY THE DISCONNECT SWITCH ON THE ELECTRIC COIL DOOR.**

**Duct Mount Installation**

**Note: Refer to submittal drawings for specific unit dimensions.**

**Figure 5 - Duct Mount Details**

- 1. Control/Coil Access Door
- 2. Lifting Lugs
- 3. Optional Uni-Strut Base




**Indoor (Inline) Installation**

**Note: Refer to submittal drawings for specific unit dimensions.**

**Figure 6 - Indoor Installation Details**

- 1. Flex Conduit for Field Wiring
- 2. Optional Uni-Strut Base
- 3. Lifting Lugs
- 4. Filter Access Door
- 5. Electric Heat Module
- 6. Blower/Motor Access Door
- 7. Service Disconnect Switch






## Heat Module Add-On Installation

Modular heat units (**Figure 7**) that are ordered to provide heat onto an existing blower only application require field mechanical and wiring installation.

1. Remove existing intake housing and lifting lugs from the blower section intake side.
2. Attach heat module to blower intake using the provided sheet metal screws and bolts. Tighten screws and bolts to compress the gasket between the heat module and the blower module.
3. Support and level the end of the heat module (end opposite the blower) with the provided equipment legs/rails.
4. Attach the intake housing to the intake side of the heater module.
5. Drill a hole in the discharge of the blower large enough to insert the discharge control sensor (if provided). Install the sensor through the hole.
6. Wire the sensor and coil as indicated on the supplied wiring schematic. Route all wiring through metal conduit.
7. After the add-on installation is complete, refer to **“Start-up Procedure”** on page 25.

**Figure 7 - Heat Module**



- |                         |                   |
|-------------------------|-------------------|
| 1. Blower               | 5. Equipment Legs |
| 2. Electric Heat Module | 6. Conduit        |
| 3. Intake Housing       | 7. Curb           |
| 4. Filters              |                   |

## ELECTRICAL

### **WARNING!!**

**Disconnect power before installing or servicing unit. High voltage electrical input is needed for this equipment. A qualified electrician should perform this work.**

Before connecting power to the heater, read and understand the entire section of this document. As-built wiring diagrams are furnished with each unit by the factory and are attached to the control module's door or provided with paperwork packet.

Electrical wiring (**Table 3**) and connections must be made in accordance with local ordinances and the National Electric Code, ANSI/NFPA 70. Verify the voltage and phase of the power supply, and the wire amperage capacity is in accordance with the unit nameplate. For additional safety information, refer to AMCA publication 410-96, *Recommended Safety Practices for Users and Installers of Industrial and Commercial Fans*.

1. **Always disconnect power before working on or near this equipment. Lock and tag the disconnect switch and/or breaker to prevent accidental power-up.**
2. An electrical drop containing the line voltage power wiring is shipped with every unit. The electrical drop should be brought through one of the conduit openings located in the base of the unit (**Figure 3**), run through the curb, and connected to a junction box inside the building.
3. A dedicated branch circuit should supply the motor circuit with short circuit protection according to the National Electric Code. This dedicated branch should run to the junction box.
4. A **separate power source should supply the electric coil power**. Power from the building breaker should be wired directly to the coil disconnect. This should be done using wire of the proper gauge as indicated in **Table 3**. **A hole must be drilled in the fan enclosure to properly run the electric coil power.**
5. Verify that the power source is compatible with the requirements of your equipment. The nameplate identifies the **proper phase and voltage** of the equipment.
6. Units shipped with a remote HMI will require a second drop through the base of the unit. It is important to route the motor wires in a separate conduit from the HMI wiring. Refer to **Figure 3**.
7. Before connecting the unit to the building's power source, verify that the power source wiring is de-energized.
8. Secure the power cable to prevent contact with sharp objects.
9. Do not kink power cable and never allow the cable to encounter oil, grease, hot surfaces, or chemicals.
10. Before powering up the unit, make sure that the fan rotates freely. Make sure that the interior of the unit is free of loose debris or shipping materials.
11. If any of the original wire supplied with the unit must be replaced, it must be replaced with type THHN wire or equivalent.


**WARNING: ELECTRIC HEATERS HAVE TWO POWER INPUTS. THE EXTERNAL DISCONNECT INTERRUPTS POWER TO THE MOTOR AND CONTROLS ONLY. THE ELECTRIC COIL POWER IS INTERRUPTED BY THE DISCONNECT SWITCH ON THE ELECTRIC COIL DOOR.**

**Table 3 - Copper Wire Ampacity**

<b>Wire Size AWG</b>	<b>Maximum Amps</b>
14	15
12	20
10	30
8	50
6	65
4	85
3	100
2	115
1	130
1/0	150
2/0	175
3/0	200
4/0	230
250	255
300	285
350	310
400	335
500	380
600	420

# Fan to Building Wiring Connection

Figure 8 - Wiring Connection Details




1. Disconnect Switch
2. Galflex Conduit (In Unit)
3. Factory Wiring
4. Field Supplied Wiring - From building power or pre-wired control panel.
5. 120V Single Phase Standing Power
6. 208-240 Single Phase
7. Three Phase

## Remote Control Panel

On units shipped with the optional remote control panel, an electrical drop containing the panel wiring is provided with the heater. There is a terminal strip inside the remote panel that matches the terminals in the heater unit. The remote panel should be wired as shown in **Figure 9**. Wiring may vary by unit, refer to electrical schematics that were provided with your unit.

Figure 9 - Typical Remote Control Panel Wiring



## Electric Cabinet Heater

On units shipped with an optional electric cabinet heater, ensure that the thermostat is set correctly while commissioning the unit and that the thermostat sensing bulb is mounted correctly in the control vestibule where the heater is located. **The stat needs to be set to 0 Degrees Fahrenheit.**

## AC Interlock

On units shipped with an optional AC interlock relay, 24V AC power from Y1 in the condensing unit or rooftop unit should be field wired to terminal block 27 in the MUA. 24V AC common from C in the condensing unit or rooftop unit should be field wired to terminal block 28 in the MUA. When these terminals are powered, heat will be locked out within the MUA.

## Motorized Intake Damper

On units shipped with the optional motorized intake damper, a power transformer is supplied with the unit if the main incoming voltage is greater than 120V. The damper motor is automatically energized when the main disconnect switch is in the ON position. No external wiring to the damper motor is required.

## Permanent Split Capacitor (PSC) Motor Speed Control


Some single-phase direct-drive fans contain speed controls that regulate the amount of voltage going to the motor. Specific PSC motors must be used in conjunction with speed controls. The speed control has a knob (**Figure 10**) with an off position along with high to low range. At high speed, the speed control allows all of the line voltage to pass directly to the motor.

A minimum speed adjustment is provided to allow independent control of the minimum speed setting. Minimum speed adjustment ensures the motor runs with sufficient torque to prevent stalling. To adjust this:

1. Motor must be in actual operating conditions to achieve proper speed adjustment. Motor will not slow down unless proper load is applied.
2. Turn main control knob to lowest speed position.
3. Locate and adjust minimum speed setting. This can be found under the speed control faceplate. Use a small screwdriver to adjust. Rotate clockwise to decrease minimum speed; counter-clockwise to increase minimum speed.
4. Motor will now operate from this preset minimum speed to full speed.

**The lowest minimum voltage that may be applied to these motors is 65V AC. Running lower voltages to the motor can cause premature failure and overheating problems.**

Figure 10 - PSC Motor Speed Control



## Electronically Commutated Motor (ECM) Speed Control

An Electrically Commutated Motor (ECM) with speed control allows for an accurate manual adjustment of the fan's speed. The benefits of using an EC motor is exceptional efficiency, performance, and motor life.

### External PWM Signal

The fan unit will be shipped with power wiring and communication wiring fed to an internal junction box. The fan is shipped with Shielded Twisted Pair (STP) wire which is used to wire to a remote PWM signal. Red wire is used to go to the positive PWM signal, black wire is used to go to the negative PWM signal. Reference schematics for all wiring connections. STP is connected to the communication wiring of the motor using wire nuts in the junction box. If a preset length of STP is provided, it will be connected to the junction box from the factory. Run the STP through any available knockout in the fan base.

### Unit Mount Controller

The RTC speed controller features a 4 digit LED display with a five button interface. All parameters can be accessed through the user menu. The percent of run speed can be changed by using the **Up** and **Down** buttons followed by pressing **Enter** (middle button) to save changes. Every **ten seconds** the display will toggle between current percentage of run speed and current RPMs. The flow index has a range of **0-100%** and is typically linear with motor RPM.


If the remote function (re) is enabled, the speed is controlled through a **0-10V** input. **0V = 0%** and **10V = 100%**, unless overridden by the low speed and high speed limits.

The speed controller requires a **24V AC** input and can locally turn the motor on and off. The motor RPM range is fully adjustable between the minimum and maximum setpoints, see LSPD and HSPD on the programming display. For more information, see the RTC control operating manual.

**For all motors except 16Z, 18Z, 20Z, 22Z, 25Z, 28Z:** If "oFF" is being displayed, and the speed is set above 300 RPM, the ECM is not receiving RPM feedback. Check that the ECM is wired correctly. Check that the motor "tyP" in the settings matches the motor manufacturer. 16Z, 18Z, 20Z, 22Z, 25Z, 28Z do not send RPM feedback.

**NOTE: A Variable Frequency Drive (VFD) is required to adjust the speed control of a non-electrically commutated 3-phase direct-drive motor.**

Figure 11 - RTC Speed Controller and Menu



## Motor Speed Controller (MSC) Installation

The Motor Speed Controller (MSC) is a versatile device able to output various signal types to many different Electrically Commutated Motors (ECMs). The MSC signal output types can be selected under the 'Motor Type' section of the MSC menu. The MSC may be installed in a fan, remotely in a kitchen space, or in a mechanical room. While this device can be mounted remotely and powered using 24V, it may also be mounted with the fan where it will be exposed to higher voltages. If installed in the fan, the electrical installation must be carried out according to the appropriate regulations (e.g., cable cross-sections, circuit breaker, protective earth [PE] connection). National and local codes must be followed during the installation process.

The MSC board may be powered through a 120VAC/24VAC CLASS 2 transformer, 120V AC/24V DC CLASS 2 power supply, or through MODBUS connections.


The MSC contains static sensitive components. Therefore, you must handle with care to avoid damage to these components. All operations concerning installation, commissioning, and maintenance must be carried out by qualified, skilled personnel who are familiar with the installation, assembly, commissioning, and operation of the electronic board and the application for which it is being used.

Ensure proper handling and avoid excessive mechanical stress. Do not bend any components when handling or installing component. **Do not touch any electronic components or contacts.**

Precautions must be adhered to during installation, testing, servicing, and repairing of this board. Component damage may result if proper procedures are not followed.

Do not install the MSC where it is subjected to adverse environmental conditions such as combustibles, oils, hazardous vapors, corrosive chemicals, excessive dust, moisture, direct sunlight, or extreme temperatures. When removing or installing the MSC to the j-box, verify the gasket is present. All electrical connections for the MSC are located on the backside of the controller. Refer to **Figure 12** for details on installation and electrical connections. When the micro USB programming port is not in use, place the weather-seal plug into the port location.

**Figure 12 - Installation/Electrical Connections**




## MSC Controls Overview

There are four buttons to navigate through the menu screens, refer to **Figure 13**.

Press the **MENU** button to access menu settings/parameters, pressing **MENU** will also back out of the current menu screen. To scroll through menus, use **UP** and **DOWN** buttons. Press the **ENTER** button to change setting/parameter selection.

To enter password, press MENU, then press **ENTER** when “Board Config” is displayed. Use **UP** and **DOWN** to scroll through numbers, press **ENTER** to advance to the next numerical setting. To save changes, press **MENU** until the screen displays “SAVE CHANGES? [ENTER] TO SAVE.” Press the ENTER button to save changes.

**Figure 13 - MSC Front Detail View**



## MSC Menu

### Board Config - Password (default is 0225)

- **Motor Type** - User may change motor type between Nidec, Telco 42, Telco 48, Ziehl, 0-10V, Other.
- **Control Type** - This setting adjusts how the fan will be controlled.
  - **Local** - The fan will be controlled by the MSC.
  - **Remote Modbus** - The fan will be controlled by another master board through the MSC. A connection between the 0-10V Out to 0-10V In must be made for start command.
  - **Remote 0-10V** - The fan will be controlled by an external 0-10V signal.
- **Speed Settings** - Provides access to speed and voltage settings.
  - **Low Speed** - Adjustable speed from 20% up to high speed setting, or 0-10V. Setting cannot go above High Speed parameter.
  - **High Speed** - Adjustable speed from 100% down to low speed setting, or 10-0V. Setting cannot go below Low Speed parameter.
  - **Set Speed%** - Adjustable speed range is dependent on Low Speed and High Speed settings. This controls the output of the motor.
  - **Voltage Range** - Only available when Motor Type “OTHER” is selected. Default setting is 24V. 5V, and 10V are also available.



- **Modbus #** - Adjustable Modbus ID. Exhaust Fan range 11-18, Supply Fan range 21 or 22. **A VFD and MSC cannot use the same Modbus #.**
- **Options**
  - **Feedback Fault** - If set to ENABLED, the MSC will monitor RPM feedback. If the MSC does not receive data for 30 seconds or 70% of the expected RPM, this fault will be displayed. **Ziehl motors do not provide feedback.**
  - **2 Speed** - The 0-10V output cannot be used when the 2 Speed or Manual Speed options are On, or if the "Control Type" is set to Modbus. When the 0-10V OUT and 0-10V IN terminals are **not** jumped together, the fan will operate at low speed. When 0-10V OUT and 0-10V IN terminals are jumped together, the fan will operate at high speed.
  - **Analog Speed** - The user may enable/disable the option, and calibrate a potentiometer for proper operation that is connected between the 0-10V OUT and 0-10V IN terminals. When enabled, you must calibrate the potentiometer. Follow the MSC's on-screen instructions. The speed will be adjustable between 0V (low speed) to 10V (high speed).
  - **Input Threshold** - When control type is set to Remote 0-10V, an input threshold will be created for motor control. Refer to **Figure 14 on page 18** for threshold examples.
    - **Zero Operation** - The user may select how the motor will operate when the 0-10V input is at 0V. The options will be Off or Low Speed (default).
    - **Threshold** - Increasing the threshold value will allow for the device to hold its voltage/RPM output while the input is between the 0 - threshold value.
  - **Restore Settings** - Provides access to restore factory settings, and test & balance settings.
    - **Factory Settings** - This will reset all values back to factory settings.
    - **T & B Settings** - This will reset all values back to last saved test & balance settings.
  - **Change Password** - Users may update the password setting to their own. Password 0225 will also be stored for backup. Both passwords will allow users to enter "Board Config" settings.

**Software Version** - Displays the current software version installed on the board.

**Faults** - This provides access to "Fault History," "Fault Totals," and "Clear Faults."


- **Fault History** - Displays fault history and board reboots in chronological order. Possible displayed faults are:
  - **No Faults** - There are no active faults with the system.
  - **Feedback Fault** - Only displayed for motors with feedback capabilities.
  - **Reboot** - Any time the fan goes from OFF to ON, this "fault" will be logged. This fault will only display in "Fault History."
  - **Modbus** - Issue with Modbus communication between the MSC and master board.
  - **Variable Device Fault** - When "Analog Speed" is selected and a potentiometer is connected, if the voltage drops below 1V, this fault will be displayed.
- **Fault Totals** - Displays amount of faults for Modbus, Feedback, Var Device, Reboot, and Total Faults.
- **Clear Faults** - Users may clear all faults from the board.

**Service** - This provides access to service settings. Password: 1234


- **Save T & B** - After the test & balance process has been completed, save adjustments under this menu.
- **IO Status** - Provides access to information about the inputs and outputs of the MSC board.
  - **V In** - Displays the incoming voltage (0-10V) to the MSC.
  - **V Out** - Displays the output voltage (0-10V) to the motor.
  - **RPM** - Displays motor RPM feedback. **Ziehl motors do not provide feedback.**
  - **PWM V** - Displays equivalent voltage reading of the PWM output to the motor.
  - **Speed%** - Displays PWM percentage output value to the motor.

# Input Threshold

## Figure 14 - Input Threshold Examples



# MSC Menu Tree




## Heater Controller

**Only Factory Service Personnel should make adjustments to the configuration menu settings.**

The heat controller features a two-line, eight character display with a three button interface. To adjust heat settings, use the **Up** and **Down** buttons. Other parameters may be accessed in the configuration menu. To access the configuration menu, press and hold the "Override" button for at least 8 seconds.

**Figure 15 - Viconics VT7225 Heat Controller**

1. **Override Button** – Press the "Override" button to scroll between the available parameters.
2. **Up Button** – Adjust value up.
3. **Down Button** – Adjust value down.



**Pswrd Set** – This allows the user to set a password to prevent unauthorized access to the configuration menu. Default value is 0. Range is 0-1000.

**MenuScro** – Removes the scrolling display and displays just the room temperature to the user. When set to on, the scroll feature is active. When set to off, the scroll feature is inactive. Default value is off. On/off option.

**°C/°F** – Sets the temperature unit between Celsius or Fahrenheit. Default is Fahrenheit.

**Unocc HT** – Unoccupied heating setpoint. Default value is 62°F (17°C). Range is 0 -180°F (-17° - 82°C).

**Heat Max** – Maximum occupied and unoccupied heating setpoint adjustment. Default value is 90°F. Range is 0 -180°F (-17 - 82°C).

**Heat Min** – Minimum occupied and unoccupied cooling setpoint adjustment. Default value is 54°F. Range is 0 -180°F (-17 - 82°C).

**Note: Heat Max has a priority over Heat Min.**

**Pband** – Adjusts the proportional band used by the room controller. Default is 3°F (1.2°C). Range is 3-10°F (1.2 - 5.6°C).

**Set Type** – Enables temporary setpoint features to any change of occupied or unoccupied setpoints. Available modes are Permanent/Temporar.

**ToccTime** – Temporary occupancy time with occupied mode setpoints when override functions are enabled. Default value is 2 hours. Range 0-24 hours.

**Cal RS** – Offset that can be added/subtracted to the actual displayed room temperature. Default value is 0.0°F/C. Range is +/- 5°F with 1° increments (+/- 2.5°C with 0.5° increments).

## Variable Frequency Drive (VFD)

**WARNING!!**

- Before installing the VFD drive, ensure the input power supply to the drive is OFF.
- The power supply and motor wiring of the VFD must be completed by a qualified electrician.
- The VFD is factory programmed, only change if replaced or ordered separately.

Consult the VFD manual and all documentation shipped with the unit for proper installation and wiring of the VFD. The VFD has been programmed by the factory with ordered specific parameters. Use **Table 4** as a guide during installation.

**Table 4 - VFD Installation Check List**

Check Off	Description
	The installation environment conforms to the VFD manual.
	The drive is mounted securely.
	Space around the drive meets the drive's specification for cooling.
	The motor and driven equipment are ready to start.
	The drive is properly grounded.
	The input power voltage matches the drive's nominal input voltage.
	The input power connections at L1, L2, and L3 are connected and tight.
	The input power protection is installed.
	The motor power connection at U, V, and W are connected and tight.
	The input, motor, and control wiring are run in separate conduit runs.
	The control wiring is connected and tight.
	NO tools or foreign objects (such as drill shavings) are in the drive.
	NO alternative power source for the motor (such as a bypass connection) is connected - NO voltage is applied to the output of the drive.

## Variable Frequency Drive (VFD) Installation

### Input AC Power

- Circuit breakers feeding the VFDs are recommended to be thermal-magnetic and fast-acting. They should be sized based on the VFD amperage and according to **Table 5 on page 24**. Refer to the installation schematic for exact breaker sizing.
- Every VFD should receive power from its own breaker. If multiple VFDs are to be combined on the same breaker, each drive should have its own protection measure (fuses or miniature circuit breaker) downstream from the breaker.
- Input AC line wires should be routed in conduit from the breaker panel to the drives. AC input power to multiple VFDs can be run in a single conduit if needed. **Do not combine input and output power cables in the same conduit.**
- The VFD should be grounded on the terminal marked PE. A separate insulated ground wire must be provided to each VFD from the electrical panel. This will reduce the noise being radiated in other equipment.

**ATTENTION: Do not connect incoming AC power to output terminals U, V, W. Severe damage to the drive will result. Input power must always be wired to the input L terminal connections (L1, L2, L3).**

### VFD Output Power

- Motor wires from each VFD to its respective motor **MUST** be routed in a **separate steel** conduit away from control wiring and incoming AC power wiring. This is to avoid noise and crosstalk between drives. An insulated ground must be run from each VFD to its respective motor. Do not run different fan output power cables in the same conduit.
- VFD mounted in ECP: A load reactor should be used and sized accordingly when the distance between the VFD and motor is greater than specified below. The load reactor should be installed within 10 feet of the VFD output:
  - 208/230V** - Load reactor should be used when distance exceeds 250 feet.
  - 460/480V** - Load reactor should be used when distance exceeds 50 feet.
  - 575/600V** - Load reactor should be used when distance exceeds 25 feet.
- VFD mounted in fan: The load reactor should be sized accordingly when the VFD is mounted in the fan.
  - 208/230V** - Load reactor is optional but recommended for 15 HP and above motors.
  - 460/480V** - Load reactor is optional but recommended for 7.5 HP and above motors.
  - 575/600V** - Load reactors are required for all HP motors.
- If the distance between the VFD and the motor is extremely long, up to 1000 FT, a dV/dT filter should be used, and the VFD should be increased by 1 HP or to the next size VFD. The dV/dT filter should be sized accordingly and installed within 10 feet of the output of the VFD.
  - 208/230V** – dV/dT filter should be used when distance exceeds 400 feet.
  - 460/480V** – dV/dT filter should be used when distance exceeds 250 feet.
  - 575/600V** – dV/dT filter should be used when distance exceeds 150 feet.
- Do not install a contactor between the drive and the motor. Operating such a device while the drive is running can potentially cause damage to the power components of the drive.
- When a disconnect switch is installed between the drive and motor, the disconnect should only be operated when the drive is in a STOP state.

## VFD Programming

### Programming


1. The Drive should be programmed for the proper motor voltage. P107 is set to 0 (Low) if motor voltage is 120V AC, 208V AC or 400V AC. P107 is set to 1 (High) if the motor voltage is 230V AC, 480V AC, or 575V AC.
2. The Drive should be programmed for the proper motor overload value. P108 is calculated as Motor FLA x 100 / Drive Output Rating (available in **Table 5 on page 24**).

#### To enter the PROGRAM mode to access the parameters:

1. Use the buttons on the VFD screen (**Figure 16**) to adjust VFD settings. Press the Mode (M) button. This will activate the password prompt (PASS).
2. Use the Up and Down buttons to scroll to the password value (the factory default password is "0225") and press the Mode (M) button. Once the correct password is entered, the display will read "P100", which indicates that the PROGRAM mode has been accessed at the beginning of the parameter menu.
3. Use the Up and Down buttons to scroll to the desired parameter number.
4. Once the desired parameter is found, press the Mode (M) button to display the present parameter setting. The parameter value will begin blinking, indicating that the present parameter setting is being displayed. The value of the parameter can be changed by using the Up and Down buttons.
5. Pressing the Mode (M) button will store the new setting and exit the PROGRAM mode. To change another parameter, press the Mode (M) button again to re-enter the PROGRAM mode. If the Mode button is pressed within 1 minute of exiting the PROGRAM mode, the password is not required to access the parameters. After one minute, the password must be re-entered to access the parameters again.

P500 parameter provides a history of the last 8 faults on the drive. It can be accessed without entering PROGRAM mode.

**Figure 16 - VFD Screen**



# ACTECH SMV VFD

## Table 5 - Cross Reference

HP	Part Number	Volts	1Ø Input	3Ø Input	Input Amps 1Ø 120V AC	Input Amps 1Ø 240V AC	Output Amps	Breaker 1Ø 120V AC	Breaker 1Ø 240V AC
0.5	ESV371N01SXB	120/240V	X	-	9.2	4.6	2.4	15	15
1	ESV751N01SXB	120/240V	X	-	16.6	8.3	4.2	25	15
1.5	ESV112N01SXB	120/240V	X	-	20	10	6	30	20

HP	Part Number	Volts	1Ø Input	3Ø Input	Input Amps 1Ø	Input Amps 3Ø	Output Amps	Breaker 1Ø	Breaker 3Ø
0.5	ESV371N02YXB	240V	X	X	5.1	2.9	2.4	15	15
1	ESV751N02YXB	240V	X	X	8.8	5	4.2	15	15
1.5	ESV112N02YXB	240V	X	X	12	6.9	6	20	15
2	ESV152N02YXB	240V	X	X	13.3	8.1	7	25	15
3	ESV222N02YXB	240V	X	X	17.1	10.8	9.6	30	20
5	ESV402N02TXB	240V	-	X	-	18.6	16.5	-	30
7.5	ESV552N02TXB	240V	-	X	-	26	23	-	40
10	ESV752N02TXB	240V	-	X	-	33	29	-	50
15	ESV113N02TXB	240V	-	X	-	48	42	-	80
20	ESV153N02TXB	240V	-	X	-	59	54	-	90

1	ESV751N04TXB	480V	-	X	-	2.5	2.1	-	15
1.5	ESV112N04TXB	480V	-	X	-	3.6	3	-	15
2	ESV152N04TXB	480V	-	X	-	4.1	3.5	-	15
3	ESV222N04TXB	480V	-	X	-	5.4	4.8	-	15
5	ESV402N04TXB	480V	-	X	-	9.3	8.2	-	15
7.5	ESV552N04TXB	480V	-	X	-	12.4	11	-	20
10	ESV752N04TXB	480V	-	X	-	15.8	14	-	25
15	ESV113N04TXB	480V	-	X	-	24	21	-	40
20	ESV153N04TXB	480V	-	X	-	31	27	-	50
25	ESV183N04TXB	480V	-	X	-	38	34	-	70
30	ESV223N04TXB	480V	-	X	-	45	40	-	80
40	ESV303N04TXB	480V	-	X	-	59	52	-	100
50	ESV373N04TXB	480V	-	X	-	74	65	-	125
60	ESV453N04TXB	480V	-	X	-	87	77	-	150

1	ESV751N06TXB	600V	-	X	-	2	1.7	-	15
2	ESV152N06TXB	600V	-	X	-	3.2	2.7	-	15
3	ESV222N06TXB	600V	-	X	-	4.4	3.9	-	15
5	ESV402N06TXB	600V	-	X	-	6.8	6.1	-	15
7.5	ESV552N06TXB	600V	-	X	-	10.2	9	-	20
10	ESV752N06TXB	600V	-	X	-	12.4	11	-	20
15	ESV113N06TXB	600V	-	X	-	19.7	17	-	30
20	ESV153N06TXB	600V	-	X	-	25	22	-	40
25	ESV183N06TXB	600V	-	X	-	31	27	-	50
30	ESV223N06TXB	600V	-	X	-	36	32	-	60
40	ESV303N06TXB	600V	-	X	-	47	41	-	70
50	ESV373N06TXB	600V	-	X	-	59	52	-	90
60	ESV453N06TXB	600V	-	X	-	71	62	-	110



## START-UP OPERATION

Before starting up or operating the unit, verify all fasteners are secure and tight. Check the set screw in the bearings, and the fan sheaves (pulleys). With power **OFF** to the unit or before connecting the unit to power, turn the fan wheel by hand. Verify it is not striking the inlet or any obstructions. If necessary, re-center.

**Special Tools Required:** Standard Hand Tools, AC Voltage Meter, Tachometer


### Start-up Procedure

1. Check all electrical connections are secure and tight.
2. Check pulley alignment and belt tension. Refer to “**Pulley Alignment/Proper Belt Tension**” on page 27.
3. Inspect the condition of the intake damper and damper linkage, if applicable.
4. Remove intake filters if not already installed, inspect the air stream for obstructions. Install intake filters.
5. Compare the supplied **motor voltage** with the fan’s nameplate voltage. If this does not match, correct the problem. Compare the supplied **coil voltage** with the coil’s nameplate voltage. If this does not match, correct the problem. If this does match, turn the coil disconnect to the **ON** position.
6. Place the external disconnect to the **ON** position to start the unit. Immediately place the disconnect switch off. **Check the rotation of the fan** with the directional arrow on the blower scroll. Reversed rotation will result in poor air performance, motor overloading and possible burnout. For units equipped with a single-phase motor, check the motor wiring diagram to change rotation. For 3-phase motors, any two power leads can be interchanged to reverse motor direction.
7. When the fan is started, observe the operation and check for any unusual noises.
8. Place the external disconnect switch back to the **ON** position. The system should be in full operation with all ducts attached. Measure the system airflow. The motor sheave (pulley) is variable pitch and allows for an increase or decrease of the fan RPM. If an adjustment is needed, refer to “**Pulley Adjustment**” on page 26. Refer to “**Pulley Combination Chart**” on page 28 for adjustment specifications.
9. Once the proper airflow is achieved, measure and record the fan speed with a reliable tachometer. **Caution - Excessive speed will result in motor overloading or bearing failure. Do not set fan RPMs higher than specified in the maximum RPM chart.** Refer to “**Troubleshooting**” on page 35 for more information.
10. Measure and record the **voltage** and **amperage** to the motor. Compare with the motor’s nameplate to determine if the motor is operating under safe load conditions.
11. Once the RPM of the ventilator has been properly set, disconnect power. Re-check belt tension and pulley alignment, refer to “**Pulley Alignment/Proper Belt Tension**” on page 27.
12. Measure and record the **voltage** and **amperage** to the electric coil and compare with the coil nameplate to determine if the coil is operating under safe load conditions. While the blower is operating, configure the thermostat for supply temperature control and disconnect one wire from the discharge air sensor or thermostat. The amp draw and voltage should be measured in the override condition to verify proper coil operation at max amperage. Reconnect all wires and dip switches to original stat.
13. Verify that the coil thermostat is operating properly. Turn the thermostat dial to a set-point warmer than the outside air temperature (if possible). With the blower running, the coil should become energized and begin to heat the air. Once the thermostat becomes satisfied, the coil should cycle off or reduce the number of energized heating stages. Turn the set-point below the outside air temperature (if the climate permits), and the electric coil should cycle off. Set the thermostat set-point to the desired setting to control either discharge air temperature or space temperature (depending on how the unit was ordered).

## Pulley Adjustment

The adjustable motor pulley is factory set for the RPM specified (**Table 6**). Speed can be increased by closing or decreased by opening the adjustable motor sheave. Two groove variable pitch pulleys must be adjusted to an equal number of turns open or closed. Any increase in speed represents a substantial increase in horsepower required by the unit. Motor amperage should always be checked to avoid serious damage to the motor when the speed is varied. Always torque set screws according to the torque specifications shown in **Figure 17**.

**Figure 17 - Adjustable Pulley**



Setscrew Thread Size	Torque (in-lbs)
No. 10 (bushing)	32
1/4" (bushing)	72
5/16"	130

**Table 6 - Maximum RPM and HP Chart**

Belt Drive		
Blower Size	Max. RPM	Max. HP
10"	1800	2
12"	1500	3
15"	1400	5
18"	1200	5
20"	1000	10
25"	900	20

Direct Drive		
Blower Size	Max. RPM	Max. HP
15D	1800	2
20D	1500	3
24D	1400	5
30D	1200	5
36D	1000	10
16Z	2400	4
18Z	3200	5
20Z	2300	5
22Z	1900	5
25Z	1800	8
28Z	1400	7

## Pulley Alignment/Proper Belt Tension


- Belts tend to stretch and settle into pulleys after an initial start-up sequence. **Do not tension belts by changing the setting of the motor pulley**, this will change the fan speed and may damage the motor.
  - To re-tension belts, turn OFF power to the fan motor.
  - Loosen the fasteners that hold the blower scroll plate to the blower.
  - Rotate the motor to the left or right to adjust the belt tension. Belt tension should be adjusted to allow 1/64" of deflection per inch of belt span. Use extreme care when adjusting V-belts as not to misalign pulleys. Any misalignment will cause a sharp reduction in belt life and produce squeaky noises. Over-tightening will cause excessive belt and bearing wear as well as noise. Too little tension will cause slippage at startup and uneven wear.
  - Whenever belts are removed or installed, never force belts over pulleys without loosening motor first to relieve belt tension.** When replacing belts, use the same type as supplied by the manufacturer. On units shipped with double groove pulleys, matched belts should always be used.
- All fasteners should be checked for tightness each time maintenance checks are performed before restarting unit.

### Belt tension examples:


- Belt span 12" = 3/16" deflection
- Belt span 32" = 1/2" deflection

Figure 18 - Pulley Alignment/Belt Tension


- A. Belt Span Length
- B. Deflection
- C. Center Distance




Correct




Incorrect



Incorrect



Incorrect



# Pulley Combination Chart


Motor RPM			1725														
<b>1/3 to 1-1/2 HP AX BELTS</b>			MOTOR PULLEY 1VL34		Dd1 1.9	Dd2 2.9	Pd1 2	Pd2 3	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0				
AK114	11	11.2	308	323	339	354	370	385	400	416	431	447	462				
<b>1/3 to 2 HP AX BELTS</b>			MOTOR PULLEY 1VL40		Dd1 2.4	Dd2 3.4	Pd1 2.6	Pd2 3.6	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0				
AK114	11	11.2	400	416	431	447	462	477	493	508	524	539	554				
AK94	9	9.2	488	506	525	544	563	581	600	619	638	656	675				
AK79	7.5	7.7	582	605	627	650	672	694	717	739	762	784	806				
AK66	6.2	6.4	701	728	755	782	809	836	863	889	916	943	970				
AK54	5	5.2	863	896	929	962	995	1028	1062	1095	1128	1161	1194				
AK46	4.2	4.4	1019	1059	1098	1137	1176	1215	1255	1294	1333	1372	1411				
AK39	3.5	3.7	1212	1259	1305	1352	1399	1445	1492	1539	1585	1632	1678				
AK32	3	3.2	1402	1455	1509	1563	1617	1671	1725	1779	1833	1887	1941				
<b>3 to 5 HP BX BELTS</b>			MOTOR PULLEY 2VP42		Dd1 2.9	Dd2 3.9	Pd1 3	Pd2 4	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
2BK160H	15.4	15.7	330	339	348	357	366	375	385	394	403	412	421	430	439		
2BK140H	13.4	13.7	378	388	399	409	420	430	441	451	462	472	483	493	504		
2BK120H	11.4	11.7	442	455	467	479	491	504	516	528	541	553	565	577	590		
2BK110H	10.4	10.7	484	497	511	524	537	551	564	578	591	605	618	631	645		
2BK100H	9.4	9.7	534	548	563	578	593	608	622	637	652	667	682	697	711		
2BK90H	8.4	8.7	595	611	628	644	661	677	694	710	727	744	760	777	793		
2BK80H	7.4	7.7	672	691	709	728	747	765	784	803	821	840	859	877	896		
2BK70H	6.4	6.7	772	794	815	837	858	880	901	923	944	965	987	1008	1030		
2BK60H	5.4	5.7	908	933	958	984	1009	1034	1059	1084	1110	1135	1160	1185	1211		
2BK55H	4.9	5.2	995	1023	1050	1078	1106	1133	1161	1189	1216	1244	1272	1299	1327		
2BK50H	4.4	4.7	1101	1132	1162	1193	1223	1254	1285	1315	1346	1376	1407	1438	1468		
<b>7-1/2 to 10 HP BX BELTS</b>			MOTOR PULLEY 2VP60		Dd1 4.3	Dd2 5.5	Pd1 4.7	Pd2 5.9	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
2BK160H	15.4	15.7	516	527	538	549	560	571	582	593	604	615	626	637	648		
2BK140H	13.4	13.7	592	604	617	630	642	655	667	680	693	705	718	730	743		
2BK120H	11.4	11.7	693	708	722	737	752	767	781	796	811	826	840	855	870		
2BK110H	10.4	10.7	758	774	790	806	822	838	854	871	887	903	919	935	951		
2BK100H	9.4	9.7	836	854	871	889	907	925	943	960	978	996	1014	1031	1049		
2BK90H	8.4	8.7	932	952	972	991	1011	1031	1051	1071	1091	1110	1130	1150	1170		
2BK80H	7.4	7.7	1053	1075	1098	1120	1143	1165	1187	1210	1232	1255	1277	1299	1322		
<b>3 to 5 HP BX BELTS</b>			MOTOR PULLEY 2VP42		Dd1 2.9	Dd2 3.9	Pd1 3	Pd2 4	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
2BSV278	27.8	28.1	184	189	194	200	205	210	215	220	225	230	235	240	246		
2BSV250	25	25.3	205	210	216	222	227	233	239	244	250	256	261	267	273		
2BSV234	23.4	23.7	218	224	230	237	243	249	255	261	267	273	279	285	291		
2BSV200	20	20.3	255	262	269	276	283	290	297	304	312	319	326	333	340		
2BSV184	18.4	18.7	277	284	292	300	307	315	323	331	338	346	354	361	369		
2BSV160	16	16.3	317	326	335	344	353	362	370	379	388	397	406	414	423		
2BSV154	15.4	15.7	330	339	348	357	366	375	385	394	403	412	421	430	439		
2BSV136	12.6	12.9	401	412	423	435	446	457	468	479	490	501	513	524	535		
2BSV124	12.4	12.7	407	419	430	441	453	464	475	487	498	509	521	532	543		
2BSV110	11	11.3	458	471	483	496	509	522	534	547	560	572	585	598	611		
<b>7-1/2 to 10 HP BX BELTS</b>			MOTOR PULLEY 2VP60		Dd1 4.3	Dd2 5.5	Pd1 4.7	Pd2 5.9	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
2BSV278	27.8	28.1	289	295	301	307	313	319	325	331	338	344	350	356	362		
2BSV250	25	25.3	320	327	334	341	348	355	361	368	375	382	389	395	402		
2BSV234	23.4	23.7	342	349	357	364	371	378	386	393	400	408	415	422	429		
2BSV200	20	20.3	399	408	416	425	433	442	450	459	467	476	484	493	501		
2BSV184	18.4	18.7	434	443	452	461	470	480	489	498	507	517	526	535	544		
2BSV160	16	16.3	497	508	519	529	540	550	561	571	582	593	603	614	624		
2BSV154	15.4	15.7	516	527	538	549	560	571	582	593	604	615	626	637	648		
2BSV136	12.6	12.9	628	642	655	669	682	695	709	722	735	749	762	776	789		
2BSV124	12.4	12.7	638	652	666	679	693	706	720	733	747	761	774	788	801		
2BSV110	11	11.3	717	733	748	763	779	794	809	824	840	855	870	885	901		
<b>15 to 20 HP BX BELTS</b>			MOTOR PULLEY 2VP75		Dd1 5.8	Dd2 7	Pd1 6.2	Pd2 7.4	TURNS ON MOTOR PULLEY								Closed
			Open														
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
2BSV278	27.8	28.1	381	387	393	399	405	411	417	424	430	436	442	448	454		
2BSV250	25	25.3	423	430	436	443	450	457	464	470	477	484	491	498	505		
2BSV234	23.4	23.7	451	459	466	473	480	488	495	502	509	517	524	531	539		
2BSV200	20	20.3	527	535	544	552	561	569	578	586	595	603	612	620	629		
2BSV184	18.4	18.7	572	581	590	600	609	618	627	636	646	655	664	673	683		
2BSV160	16	16.3	656	667	677	688	698	709	720	730	741	751	762	773	783		
2BSV154	15.4	15.7	681	692	703	714	725	736	747	758	769	780	791	802	813		
2BSV136	12.6	12.9	829	842	856	869	883	896	909	923	936	949	963	976	990		

\*\* 2HP Motors on 20 IN Blowers use 2VP42 Pulleys


## Sequence of Operation

The main power supply provides power to both the motor controls and the coil. The blower interlock relay is the common link between the two circuits, as shown below. Once in normal operation, the coil modulating stage will energize first and then subsequent power stages as required.

### Main Circuit



## Optional Remote Panel Circuit



## Silicon Controlled Rectifier (SCR) Electrical Control

The electric coils on the heater are controlled using Silicon Controlled Rectifier (SCR) controls. SCR is a time proportioning type controller that modulates the heater and supplies the exact amount of power to match heating demand of the system.

During modulation (proportional) control of the heater, an electric signal (0-10V DC) from a proportional thermostat is transmitted to the stage controller. The thermostat, which may be either a duct type for fresh make-up air or a room sensor thermostat for zone heating. The stage controller activates the modulating stage(s) of the electric heater. The heater is electronically controlled to provide 0 to 100% of its capacity to heat the space.

Depending on the space's thermostat demand, the heater is pulsed in different proportions of ON time and OFF time to match the heating demand. A modulation control can maintain an accurate room or discharge temperature without the typical variations of the ON/OFF method.

An example of proportional control would be when the heater element is operating at 10% of its capacity, 10% ON and 90% OFF.

Heaters that use more than one modulating stage use an ON/OFF control for supplemental stages.

## Modulating Coil Thermostat Settings

To test and verify all coil circuits during startup, perform the following:

### Thermostat with Dip Switch Settings

- Discharge Control: Disconnect one wire from the discharge air sensor to simulate a call for maximum amperage.
- Space control:
- Set the Thermostat Dip switch to discharge control.
- Once maximum amperage is achieved and tested, configure wiring and Dip switches to their original state.

**Table 7 - Thermostat Dip Switch Settings**

Discharge Control		Space Control	
S1	On	S1	Off
S2	Off	S2	On
S3	On	S3	On

### Thermostat without Dip Switch Settings

- Press the override button for eight seconds to access settings menu. Use the override button to scroll through the menu to the "Heat Max" setting. Use the up arrow button to change the "Heat Max" setting to 110°F.
- Press the override button to save changes. Let the controller idle in order to exit the settings menu.
- After the controller has exited the settings menu, change the "Heating" set point to 110°F. This will simulate a call for maximum amperage.
- Once maximum amperage is achieved and tested, adjust the "Heat Max" setting to 90°F. Change "Heating" set point to desired temperature.


## SCR Electrical Circuit Check

Components and electrical wiring will vary depending on heater model and insert. Refer to schematics provided with unit for appropriate electrical wiring checks.

- Verify the automatic and manual cutout switches are in their closed position.
- Verify electrical wiring and component connections are secure and tight.
- Check for air flow, and air flow switch operation. If the switch is not closed during operation, verify the tube is properly installed.
- Verify the control setting is set to 0-10V DC on the stage control board.
- Check for 0-10V DC between (-) to (+) connections.
- When there is a call for heat, verify there is 24V AC between interlock connection "I" and common connection "C".
- When the unit is operating at 50% demand, the green LED should blink. If the light is not blinking, there may be an issue with the stage control board.
- Check for 24V AC at control fuse (labeled CF on heater schematics).
- Check SSR output terminals. There should be 0V DC when the demand is 0% and 24V DC when the demand is 100%. If the voltage readings are incorrect, there may be an issue with the stage control board.
- If the heater is equipped with multiple heating stages, verify operation of contacts. When the heating unit is at 100% demand, there should be 24V AC present at the corresponding contactor coil. The contacts should be closed.

If any components or wiring are found defective during these checks, repair or replace as required.

**Figure 19 - Typical Heater Insert Wiring**






## Components

The following image and list outlines the common electric heater components and their functions.

**Figure 20 - Typical Cabinet**




1. Motor Disconnect Switch - Interrupts power to blower motor and controls.
2. Motor Starter - Contactor with overload protection to start and protect motor.
3. Airflow Switch - A safety device insuring proper air flow during coil operation.
4. Automatic Reset Thermal Limit - Safety device that prevents the coil from overheating.
5. Stage Controller - Controls multiple heating stages in a pre-determined sequence. Works in conjunction with a proportional thermostat (not shown). A sensor is mounted in blower for discharge control. The set-point is mounted remotely for either space control or discharge control.
6. Coil Termination - Wired connection to heating coil element.
7. Silicon Control Rectifier (SCR) - Modulates power to the electric coil.
8. Fuse Blocks - Provides over-current protection.
9. Control Transformer - 120V primary; 24V secondary control transformer.
10. Coil Contactor - Energizes coil when there is a signal from step controller.
11. Inline Fuse - Provides over-current protection.
12. Terminal Strip - Central location to terminate control wiring. This should be used for troubleshooting.
13. Circuit Breaker - Protects electrical components from high current spikes.
14. Power Transformer - Installed when motor voltage is greater than 120V. Used to provide 120V service to controls.
15. Freeze-Stat Thermostat (Optional) - De-energizes blower motor if the discharge air temperature falls below the set point.
16. Coil Disconnect Switch - The disconnect switch is mounted with the coil termination blocks. When the disconnect switch is used, the power to the coil elements will be interrupted.

## Remote Panel Option

The remote panel is a device used to control the operation of the heater from a remote location. This unit is available in both a “2 Position” and “3 Position” configuration, and with or without a cooling output. It also will accommodate both discharge and space heating configurations. It is important to understand the following remote panel controls and uses:

**Figure 21 - Remote Heater Controls**



1. Blower On/Blower Off Switch - Used to control blower operation and tempering mode of unit. The **Blower On** position sends power to the blower motor and the heater begins to ventilate. The **Blower Off** position turns the blower and heating functionality off. This switch is disabled when the “2 Position” remote panel is ordered and fan power is then controlled by the pre-wire package.
2. Lights - Displays the current status of unit features. The light definitions are as follows:
  - POWER** - Illuminated when there is power to remote panel.
  - BLOWER ON** - Illuminated when the blower motor is powered.
  - HEAT ON** - Illuminates after heat circuit is energized.
  - LOW TEMP** - (Optional) Illuminated when the Freeze-stat turns off blower.
  - CLOGGED FILTER** - (Optional) Illuminated when the intake filters are dirty.
3. Temperature Control - Controls the discharge temperature of a standard unit. Can be configured to control space temperature.
4. Heat/Vent Switch - This switch is used to control the tempering mode of the unit. The **VENT** position will prevent the burner from operating and the heater will deliver untempered air. The **HEAT** position will force the heat circuit on and the unit will heat the incoming air. This switch becomes a Heat/Vent/Cool switch when the cooling interlock is ordered. This option provides a 120V cooling output from the remote panel.

## Troubleshooting

The following table lists causes and corrective actions for possible problems with the fan units. Review this list prior to consulting manufacturer. The following table lists causes and corrective actions for possible problems with the fan units. Review this list before consulting manufacturer.

### Airflow Troubleshooting Chart

Problem	Potential Cause	Corrective Action
Fan Inoperative	Blown fuse/Open circuit breaker	Check amperage.
		Check fuse, replace if needed.
		Check circuit breaker.
	Disconnect switch in "OFF" position	Place switch to the "ON" position.
	Incorrect wiring to motor	Inspect motor wiring. Verify connections with wiring diagram located on fan motor.
	Broken fan belt	Replace belt.
Motor Overload	Motor starter overloaded	Check amperage. Reset starter.
	Incorrect fan rotation	Verify that the fan is rotating in the direction shown on rotation label.
	Fan speed is too high	Reduce fan RPM.
	Incorrect wiring to motor	Inspect motor wiring. Verify connections with wiring diagram located on fan motor.
	Overload in starter set too low	Set overload to motor's FLA value.
	Motor HP too low	Determine if HP is sufficient for job.
Insufficient Airflow	Duct static pressure lower than design	Reduce fan RPM.
	Incorrect fan rotation	Verify that the fan is rotating in the direction shown on rotation label.
	Poor outlet conditions	Check duct and connections. There should be a straight duct connection to the outlet.
	Intake damper not fully open	Inspect damper linkage. If the linkage is damaged, replace damper motor.
	Duct static pressure higher than design	Check ductwork. Adjust/resize to eliminate or reduce duct losses.
	Blower speed too low	Increase fan RPM. Do not overload motor.
	Supply grills or registers closed	Open/Adjust.
	Dirty/clogged filters	Clean filters. Replace filters if they cannot be cleaned or are damaged.
Excessive Airflow	Belt slippage	Adjust belt tension.
	Blower speed too high	Reduce fan RPM.
	Filters not installed	Install filters.
Excessive Vibration and Noise	Duct static pressure lower than design	Reduce fan RPM.
	Damaged/Unbalanced wheel	Replace wheel.
	Misaligned pulleys	Align pulleys.
	Fan is operating in unstable region of fan curve	Refer to performance curve for fan.
	Bearings need lubrication/Damaged bearing	Lubricate bearings, replace if damaged.
	Fan speed is too high	Reduce fan RPM.
	Dirty/oily belt(s)	Clean belt(s).
	Belt(s) too loose	Adjust, replace if necessary.
Worn belt(s)	Replace belt(s).	

<b>Problem</b>	<b>Potential Cause</b>	<b>Corrective Action</b>
Insufficient Heating	Blown fuse(s)	Inspect fuses. Replace if needed.
	Thermostat settings too low	Increase thermostat setting.
	Excessive Airflow	Reduce fan RPM.
	Insufficient coil power	Check incoming voltage and amperage with all coil stages on and compare to nameplate values.
No Heat	Blown fuse(s)	Inspect fuses. Replace if needed.
	Airflow switch not energized	Increase fan RPM (Sensing tube should be curved toward air flow)
	Hi-limit activation	Insufficient airflow. Increase fan RPM.
	Improper coil wiring	Inspect coil power wiring.

## MSC Troubleshooting

Fault	Problem	Potential Cause	Corrective Action
Feedback Fault	Feedback Fault on MSC Display	Disconnected/faulty wiring	Secure connections to fan. If faulty wiring is found, repair or replace as required.
		No feedback for 30 seconds	Check parameters
		Less than 70% of RPM	Check duct/fan for obstructions.
Modbus	Modbus fault on MSC Display	Faulty Cat 5 connection/cable	Find and replace faulty cable
		ECPM03 does not recognize device	Verify Modbus # on device is set correctly.
Variable Device Fault	Motor not responding to changes made on variable device (potentiometer)	Defective potentiometer	Replace potentiometer
		Faulty wiring to motor	Find and replace faulty wiring.
Motor not responding	Motor not functioning as expected	2-Speed switch not working	Check switch and wiring.
		Wiring to motor defective	Find and replace faulty wiring.
		Check for other faults on MSC display	If no other faults are present, motor maybe defective.

### TURN OFF POWER TO THE MOTOR WHILE PROGRAMMING THIS DEVICE.

- If the device has a potentiometer or a 2-Speed switch, a jumper wire can be placed in between the 10V In and 10V Out terminals to rule out a defective device. This will cause the motor to go to HIGH SPEED.
- The IO STATUS menu can be used to verify the inputs and outputs of the device are functioning as expected.
- The FAULT HISTORY menu can be used to keep track of faults while working on the device.

## MAINTENANCE

To guarantee trouble-free operation of this heater, the manufacturer suggests following these guidelines. Most problems associated with fan failures are directly related to poor service and maintenance.

Please record any maintenance or service performed on this fan in the documentation section located at the end of this manual.

**WARNING: ELECTRIC HEATERS HAVE TWO POWER INPUTS. DO NOT ATTEMPT MAINTENANCE ON THE HEATER UNTIL BOTH THE MOTOR AND COIL ELECTRICAL SUPPLY HAVE BEEN COMPLETELY DISCONNECTED.**

### General Maintenance

1. Fan inlet and approaches to ventilator should be kept clean and free from any obstruction.
2. All fasteners and electrical connections should be checked for tightness each time maintenance checks are performed before restarting unit.
3. These units require very little attention when moving clean air. Occasionally oil and dust may accumulate, causing imbalance. If the fan is installed in a corrosive or dirty atmosphere, periodically inspect and clean the wheel, inlet, and other moving parts to ensure smooth and safe operation.
4. Motors are normally permanently lubricated. **Caution: Use care when touching the exterior of an operating motor. Components may be hot enough to burn or cause injury.**
5. The electric coil should be kept free of dirt and foreign matter that may cause uneven air patterns. Hot spots on the coil can shorten the life of the coil.

### 2 Weeks After Start-up

1. Belt tension should be checked after the first 2 weeks of fan operation. **See “Pulley Alignment/ Proper Belt Tension” on page 27.**
2. All fasteners should be checked for tightness each time maintenance checks are performed before restarting unit.
3. Inspect the electric coil. All elements should be in the proper location and clean. If an element is missing or broken, replace coil immediately.

### Every 3 Months

1. Belt tension should be checked quarterly. **See “Pulley Alignment/Proper Belt Tension” on page 27.** Over-tightening will cause excessive bearing wear and noise. Too little tension will cause slippage at start-up and uneven wear.
2. Filters need to be cleaned and/or replaced quarterly, and more often in severe conditions. Washable filters can be washed in warm soapy water. When re-installing filters, be sure to install with the **airflow in the correct direction** as indicated on the filter.
3. Inspect the electric coil. All elements should be in the proper location and clean. If an element is missing or broken, replace coil immediately.

### Yearly

1. Inspect bearings for wear and deterioration. Replace if necessary.
2. Inspect belt wear and replace torn or worn belts.
3. Inspect bolts and set screws for tightness. Tighten as necessary.
4. Inspect motor for cleanliness. Clean exterior surfaces only. Remove dust and grease from the motor housing to ensure proper motor cooling. Remove dirt from the wheel and housing to prevent imbalance and damage.
5. Inspect the electric coil. All elements should be in the proper location and clean. If an element is missing or broken, replace coil immediately.

## Unit Filters

**Table 8 - Filter Quantity Chart**

<b>Intake</b>	<b>16" x 20"</b>	<b>20" x 25"</b>
Size 1 Standard Sloped	2	-
Size 2 Standard Sloped	-	2
Size 1 Modular Sloped	3	-
Size 2 Modular Sloped	-	3
Size 3 Modular Sloped	6	-
Size 4 Modular Sloped	10	-
Size 5 Modular Sloped	-	8
Size 1 V-Bank	-	3
Size 2 V-Bank	8	-
Size 3 V-Bank	-	8
Size 4 V-Bank	15	-
Size 5 V-Bank	-	12
Size 1 Inline	1	-
Size 2 Inline	-	1
Size 3 Inline	-	2

## Start-Up and Maintenance Documentation

**START-UP AND MEASUREMENTS SHOULD BE PERFORMED AFTER THE SYSTEM HAS BEEN AIR BALANCED (Warranty will be void without completion of this form)**

### Job Information

Job Name	
Address	
City	
State	
Zip	
Phone Number	
Fax Number	
Contact	
Purchase Date	

Service Company	
Address	
City	
State	
Zip	
Phone Number	
Fax Number	
Contact	
Start-up Date	

### Unit Information

Refer to the start-up procedure in this manual to complete this section.

Name Plate and Unit Information	
Model Number	
Serial Number	
Coil Voltage	
Coil Hertz	
Coil Phase	
Coil FLA	
Motor HP	
Motor Volts	
Motor Hertz	
Motor Phase	
Motor FLA	
# of Steps	
Blower Pulley	
Motor Pulley	
Belt Number	

Field Measured Information	
Coil Voltage	
Coil Amperage	
Motor Voltage	
Motor Amperage**	
RPM	
Thermostat Setpoint	
Temperature Control	Discharge: Space:
# of Operating Steps	

Airflow Direction	Correct	
	Incorrect	

\*\*If measured amps exceed the FLA rating on the nameplate, fan RPM must be reduced to decrease the measured amps below the nameplate FLA rating.

### CLEANING & MAINTENANCE RECORD

Date	Service Performed